

2005 GENERAL INFORMATION

Maintenance & Lubrication - XLR

SPECIFICATIONS

CAPACITIES - APPROXIMATE FLUID

The following approximate capacities are given in English and metric conversions. See **Fluid and Lubricant Recommendations** for more information. All capacities are approximate. When adding, be sure to fill to the approximate level, as recommended in this manual. Recheck fluid level after filling.

Capacities - Approximate Fluid

Application	Capacities	
	English	Metric
Cooling System		
• 4.6L	14.8 qt	14.0 L
Engine Oil with Filter		
• 4.6L	8.0 qt	7.6 L
Engine Oil without Filter		
• 4.6L	7.5 qt	7.1 L
Fuel Tank	18.0 gal	68.0 L
Automatic Transaxle - 5L50-E		
• Automatic - Complete Overhaul/Dry	9.0 qt	8.5 L

FLUID AND LUBRICANT RECOMMENDATIONS

The Recommended Fluids and Lubricants information will only be found in the Owner's Manual. Refer to the Maintenance Schedule subsection of the Owner's Manual.

You may be able to use the Search information function using the words Fluids or Lubricants.

TIRE INFLATION PRESSURE SPECIFICATIONS

Tire Inflation Pressure Specifications

The tire pressures in the table are the correct inflation pressures for the factory installed tires when they're cold. "Cold" means the vehicle has been sitting for at least three hours or driven no more than 1 mile (1.6 km). Inspect the tires inflation pressure when the tires are cold.

	Specification

2005 Cadillac XLR

2005 GENERAL INFORMATION Maintenance & Lubrication - XLR

Application	The tire pressures in the table are the correct inflation pressures	Specification
Compact Spare	420 kPa	60 psi
Front and Rear Tires	210 kPa	30 psi

MAINTENANCE ITEMS

The Normal Maintenance Replacement Parts information will only be found in the Owner's Manual. Refer to the Maintenance Schedule subsection of the Owner's Manual.

You may be able to use the Search information function using the words Replacement Parts.

MAINTENANCE

MAINTENANCE SCHEDULE

The Maintenance Schedule information will only be found in the Owner's Manual. Refer to the Maintenance Schedule subsection of the Owner's Manual.

You may be able to use the Search information function using the words Scheduled Maintenance.

GM OIL LIFE SYSTEM- RESETTNG

This information is no longer published in the service manual. This information will be found within Engine Oil Life System in the Owner's Manual. Refer to Category Service and Appearance Care, then Checking Things Under the Hood, and then subsection Description and Operation.

You may be able to use the Search information function using the words Oil Life.